


SPARE PARTS EXPLODED VIEW GAS-WALL BOILER ATM. BURNER Model CARES XC - HS XC - EGIS XC

R8218623-05 - 02/04/2026



EN FR IT ES DE NL

1	3301685	CARES XC 10 FF NG	02-2021	-
2	3301684	CARES XC 15 FF NG	02-2021	-
3	3301683	CARES XC 18 FF NG	02-2021	-
4	3301682	CARES XC 24 FF NG	02-2021	-
5	3301689	HS XC 10 FF NG	03-2021	-
6	3301688	HS XC 15 FF NG	03-2021	-
7	3301687	HS XC 18 FF NG	03-2021	-
8	3301686	HS XC 24 FF NG	03-2021	-
9	3302267	EGIS XC 15 FF NG	04-2022	-
10	3302266	EGIS XC 24 FF NG	04-2022	-
11	4129051	CARES XC SYSTEM 24 FF NG	04-2026	-
Col	Reference	Model type	Begin	End



100
200
300
400



☰	Description	Manf. Pt. N	Type	CARES XC 10 FF CARES XC 15 FF CARES XC 18 FF CARES XC 24 FF HS XC 10 FF HS XC 15 FF HS XC 18 FF HS XC 24 FF EGS XC 15 FF EGS XC 24 FF CARES XC SYS24 FF																		0-6 31	
				1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	From	to
0100	BURNER ASSEMBLY																						
0101	ELECTRODE (IGNITION/IONIZATION)	65115802		•	•	•	•	•	•	•	•	•	•	•									
0110	PANELS (KIT)	65106298		•	•	•	•	•	•	•	•	•	•	•									
0111	HEAT EXCHANGER (CU)	65120314		•	•	•	•	•	•	•	•	•	•	•									
	HEAT EXCHANGER (Cu)	65106297											•	•									
0112	BURNER 11NP	65106294		•	•	•	•	•	•	•	•	•	•	•									
0113	GAS MANIFOLD 11 INJ. D:1.32	65106302	G20	•	•	•	•	•	•	•	•	•	•	•									
0200	GAS SECTION																						
0201	GAS VALVE	65115771		•	•	•	•	•	•	•	•	•	•	•									
0204	SPARK GENERATOR	65115791-01		•	•	•	•	•	•	•	•	•	•	•									
0214	PIPE (GAS VALVE/BURNER)	65115772		•	•	•	•	•	•	•	•	•	•	•									
0216	GROMMET	60000624		•	•	•	•	•	•	•	•	•	•	•									
0217	CH ADAPTER 3/4	65114929		•	•	•	•	•	•	•	•	•	•	•									
0218	DHW ADAPTER 1/2	65114930		•	•	•	•	•	•	•	•	•	•	•									
0251	EPDM PIPE	65115773		•	•	•	•	•	•	•	•	•	•	•									
0261	CLIP	60001861		•	•	•	•	•	•	•	•	•	•	•									
0270	GASKET (SPARK GENERATOR)	574279		•	•	•	•	•	•	•	•	•	•	•									
0281	O-RING 22.22X2.62	65104304		•	•	•	•	•	•	•	•	•	•	•									
0283	O-RING 17.17X1.78	65104303		•	•	•	•	•	•	•	•	•	•	•									
0300	FAN ASSEMBLY																						
0302	AIR PRESSURE SWITCH 50 Pa	65104671-01		•	•	•	•	•	•	•	•	•	•	•									
0303	FAN - 32W - 24KW – VETURI 27,9	65121235		•	•	•	•	•	•	•	•	•	•	•									
0310	AIR CONNECTION	65115914		•	•	•	•	•	•	•	•	•	•	•									
0314	COMBUSTION CHAMBER 24 FF	65115800		•	•	•	•	•	•	•	•	•	•	•									
0315	CONDENSATE TRAP	65105349		•	•	•	•	•	•	•	•	•	•	•									
0316	PANEL (INSULATION - FAN)	65104305		•	•	•	•	•	•	•	•	•	•	•									
0317	SUPPORT (AIR PRESSURE SWITCH)	65115812		•	•	•	•	•	•	•	•	•	•	•									
0318	VENTURI 15/24FF	65106516		•	•	•	•	•	•	•	•	•	•	•									
0319	RESTRICTOR KIT	60001598		•	•	•	•	•	•	•	•	•	•	•									
0374	CABLE INLET RUBBER WASHER	60000716		•	•	•	•	•	•	•	•	•	•	•									
0400	SEALED CASE																						
0401	EXPANSION VESSEL 8L	65104261		•	•	•	•	•	•	•	•	•	•	•									
0410	PANEL (COMBUSTION CHAMBER)	65106296		•	•	•	•	•	•	•	•	•	•	•									
0412	SPRING FRONT PANEL (KIT)	65107048		•	•	•	•	•	•	•	•	•	•	•									
0413	AIR RETURN COVER	65104249						•	•	•	•												
0414	PANEL (FRONT - SEALED CHAMBER)	65105678-02		•	•	•	•	•	•	•	•	•	•	•									
0416	SIDE PANELS LEFT + RIGHT - WHITE	65115804		•	•	•	•	•	•	•	•	•	•	•									
0417	CASE PANEL (FRONT)	65115823		•	•	•	•							•									
	CASE PANEL (FRONT)	65115824						•	•	•	•	•	•	•									
0420	EXPANSION VESSEL SUPPORT	65104696		•	•	•	•	•	•	•	•	•	•	•									




Gas-wall boiler atm. burner




Gas-wall boiler atm. burner

800



900



5000

5001	5002
Transf. gaz Conv. gas Trasf. gas Transf. gas	Transf. gaz Conv. gas Trasf. gas Transf. gas
> G31 (LPG - GPL)	> G20 (NAT - MET)

LIST OF THE ABBREVIATIONS

HW	: Hot water.
CW	: Cold water.
C	: Ceramic resistance (normal heating).
Ca	: Ceramic resistance (accelerated heating)
TP	: Immersion heater.
1F	: With fittings.
2F	: Without fittings.
3F	: With fittings and another outlet connection.
AMI	: With mixing valve.
SMI	: Without mixing valve.
PUISS	: Power of th appliance.
PN	: Appliance with normal pression.
LP	: Appliance with low pression.
PV	: Appliance with variable power.
PF	: Appliance with fixed power.

IDENTIFICATION PLATE

SERIAL NUMBER

10 Characters :	04 05 125 011	Sequential number Manufacturing day Year of manufacture
11 Characters :	1 95 065004 - 31	Technical number of the appliance Sequential number Year of manufacture
Month of manufacture : from 1 to 9 → Jan. to Sep., O → Oct., N → Nov., D → Dec.		
19 Characters :	08 05 0013199 900640031	Product reference Sequential number
Year of manufacture Month of manufacture		
20 Characters :	3675007 XX 2 07 070 00315	Sequential number Manufacturing day Year of manufacture
Product reference Millenium of manufacture		
21 Characters :	3675007 XX 07 070 0000315	Sequential number Manufacturing day
Product reference Year of manufacture		